

FIG. 1




FIG. 2




FIG. 3

	MAIN SWITCH OFF		MAIN SWITCH ON	
	AC ADAPTOR OFF	AC ADAPTOR ON	AC ADAPTOR OFF	AC ADAPTOR ON
SOFTWARE SWITCH OFF	CHARGE : IMPOSSIBLE DISCHARGE : 0 (ONLY SELF-DISCHARGE OF BATTERY) MOTOR OPERATION : IMPOSSIBLE			CHARGE : POSSIBLE DISCHARGE : CPU IDLE POWER (SEVERAL MILLI-AMPERES) MOTOR OPERATION : IMPOSSIBLE
SOFTWARE SWITCH ON				CHARGE : POSSIBLE (OVER- DISCHARGE CHECK REQUIRED) DISCHARGE : LOGIC (AC) AND MOTOR (BATTERY) MOTOR OPERATION : ONLY PAN/ TILT POSSIBLE

FIG. 4




FIG. 5




FIG. 6




FIG. 7